

# Site Master™

Handheld Cable & Antenna Analyzer Featuring Classic and Advanced Modes

# S331L

2.0 MHz to 4.0 GHz Cable & Antenna Analyzer 50 MHz to 4.0 GHz Power Meter



#### Introduction

Anritsu introduces its ninth generation, compact handheld Cable & Antenna Analyzer for installation and maintenance of antenna systems.

# **Optimized for Field Use**

- > 8 Hour Battery Life
- Rugged and Reliable
- Instant On from Standby Mode
- Highest RF Immunity
- Built-in InstaCal™ Module
  - Fast, One-connection Calibration
- FlexCal™ Calibration
  - One Calibration for All Frequencies

- Optical connector inspection with IEC 61300-3-35 based Pass/Fail standard (Requires USB Video Inspection Probe, sold separately)
- Built-in Power Meter
- High Accuracy USB Power Meter (Requires USB Sensor, sold separately)
- Impact, Dust, and Splash Resistant
- Smallest, Lightest Site Master™

## Easy to Use

- Integrated Help Function
- S331D-like Classic Mode
- S331E-like Advanced Mode
  - Additional Markers
  - Customizable Shortcuts
  - Full-screen View

- Multiple USB Ports
- 800 x 480 7" TFT Touch Screen
  - Alphanumeric Keyboard
  - EZ Name Quick Matrix
- Backlit Keypad
- easyTest™

## **Efficient Sweep Management**

- Internally Store >1000 Files
  - Sweeps, Setups, Screen Shots
- Line Sweep Tools (LST) Software
  - Edit Sweeps, Rename, Archive
  - Generate PDF or HTML Reports

- Fast Preview of Stored Sweeps
- Standard \*.dat Sweep File Format
- Compatible with HHST
  - Widely Accepted by Operators
- Location Data with Compatible USB GPS Module



Site Master<sup>™</sup> S331L Cable & Antenna Analyzer Featuring 7.0 in Daylight Viewable Touch Screen Compact Size: 250 mm x 177 mm x 61 mm (10.0 in x 7.1 in x 2.4 in), Lightweight: < 2.0 kg (4.4 lb)

## **Table of Contents**

Definitions	3
Cable and Antenna Analyzer	
Internal Power Meter	
High Accuracy Power Meter	
Video Inspection Probe	7
General Specifications	
Anritsu Tool Box and Line Sweep Tools	
easyTest Tools (for your PC)	9
Ordering Information	
Calibration and Extended Warranty Options	
Calibration Only Options	
Standard Accessories	
USB Power Sensors	
Optional Accessories	
Documentation	16

# **Definitions**

All specifications and characteristics apply to Revision 2 instruments under the following conditions, unless otherwise stated:

Warm-Up Time After 5 minutes of warm-up time, where the instrument has completely stabilized to the ambient

temperature.

Frequency Reference Internal frequency reference is used.

Calibration Instrument is within the recommended calibration cycle of 12 months. Cable and Antenna Analyzer

measurements applicable after standard OSL calibration is performed using Anritsu calibration components

components.

Typical Performance Typical specifications in parenthesis () describe performance that will be met by a minimum of 80% of all

products. They do not include guard bands and are not warranted.

Typical specifications that are not in parenthesis are not tested and not warranted. They are generally

representative of the nominal characteristic performance.

Uncertainty A coverage factor of k = 2 is applied to the measurement uncertainties to facilitate comparison with other

industry monitors.

All specifications subject to change without notice. For the most current data sheet, please visit the Anritsu

web site: www.anritsu.com



# Cable and Antenna Analyzer

#### Measurements

Measurements VSWR

Return Loss

Cable Loss (One Port)

Distance-to-Fault (DTF) Return Loss

Distance-to-Fault (DTF) VSWR

Smith Chart 50  $\Omega$ / 75  $\Omega$  (Advanced Mode Only)

1-Port Phase (Advanced Mode Only)

Transmission with External Sensor (Advanced Mode Only)

#### Setup Parameters-Classic Mode

Measurement Display Single Display with independent markers

Frequency F1/F2

DTF D1/D2, DTF Aid, Cable Loss, Propagation Velocity, Cable type
Windowing Rectangular, Normal Side Lobe, Low Side Lobe, Minimum Side Lobe

Amplitude Top, Bottom Auto Scale, Full Scale

Sweep Data Points, Run/Hold, Single/Continuous, RF Immunity (High/Low), RF Power in Hold (On/Off), Trace

Data Points 130, 259, 517, 1033, 2065

Markers 1 to 6 (On/Off), Delta Markers 2 to 4 (Ref M1), Marker to Peak/Valley, Marker Table, Marker 5

(Peak/Valley between M1 & M2), Marker 6 (Peak/Valley between M3 & M4), Independent Markers for

Frequency and Distance Measurements

Traces Copy Trace To Memory, Trace Display, Trace Math [Trace - Memory, Trace + Memory, (Trace + Memory)/2]

Limit Line On/Off, Edit Value, Limit Alarm, Pass/Fail On/Off, Limit Preset

Calibration Start Calibration, Cal Info, Cal Correction (On/Off),

Cal Method (OSL, InstaCal™), Cal Type (Standard, FlexCal™)

Save/Recall Setups, Measurements, Screen Shots

#### **Setup Parameters-Advanced Mode**

Measurement Display Single/Dual Display with independent markers

Frequency Start Frequency (F1), Stop Frequency (F2)

DTF Start Distance (D1), Stop Distance (D2), Units m/ft, DTF Aid, Cable List, Cable Loss, Propagation Velocity

Windowing Rectangular, Normal Side Lobe, Low Side Lobe, Minimum Side Lobe

Amplitude Top, Bottom, Auto Scale, Full Scale

Sweep Data Points, Run/Hold, Single/Continuous, RF Immunity (High/Low), RF Power in Hold (On/Off)

Data Points 130, 259, 517, 1033, 2065

Markers 1 to 8 (On/Off), Delta Markers 2 to 8 (Ref M1), Marker Tracking (On/Off), Marker to Peak/Valley,

Marker Table, Marker 5 & 7 (Peak/Valley between M1 & M2), Marker 6 & 8 (Peak/Valley between M3 & M4),

Independent Markers for Frequency and Distance Measurements

Traces Copy Trace to Memory, Trace Display, Trace Math [Trace - Memory, Trace + Memory, (Trace + Memory)/2]

Limit Line Active Limit (Upper/Lower), Limit State (On/Off), Move Active Limit, Edit Segments (42 upper and 42 lower

segments maximum), Limit Alarm, Pass/Fail On/Off, Limit Preset

Calibration Start Calibration, Cal Info, Cal Correction (On/Off),

Cal Method (OSL, InstaCal™, Transmission, OSL + Transmission), Cal Type (Standard, FlexCal™)

Save/Recall Setups, Measurements, Screen Shots

Frequency

Frequency Range 2 MHz to 4 GHz Frequency Accuracy ± 5 ppm @ 23 °C ± 3 °C

Frequency Resolution 1 kHz

**Power** 

Output Power –3 dBm, typical

Interference Immunity

On-Channel +17 dBm outside calibrated sweep range
On-Frequency +13 dBm within calibrated sweep range

Measurement Speed

Return Loss  $\leq$  1.50 ms/data point, RF immunity low, typical Distance-to-Fault  $\leq$  1.75 ms/data point, RF immunity low, typical

Return Loss

Measurement Range 0 to 60 dB

Resolution 0.01 dB

**VSWR** 

Measurement Range 1 to 65

Resolution 0.01



# **YY** Cable and Antenna Analyzer (continued)

#### **Cable Loss**

Measurement Range 0 to 30 dB Resolution 0.01 dB

#### Distance-to-Fault

Vertical Range Return Loss 0 to 60 dB Vertical Range VSWR 1 to 65

Fault Resolution (meters)  $(1.5 \times 10^8 \times \text{vp})/\Delta F$  (vp = propagation velocity,  $\Delta F$  is F2 – F1 in Hz)

Horizontal Range (meters) 0 to (Data Points - 1) x Fault Resolution, to maximum of 1500 meters (4921 ft)

# 1-Port Phase (Advanced Mode Only)

Measurement Display Range -450 ° to +450 °

Resolution 0.01°

#### Smith Chart (Advanced Mode Only)

Impedance 50 Ω, 75 Ω Resolution 0.01

## Transmission Ext Sensor (Advanced Mode Only)

Measurement Display Range -100 dB to +100 dB


> Resolution 0.01 dB

# Measurement Accuracy (at 23 °C ± 3 °C)

≥ 38 dB, InstaCal<sup>™</sup> calibration Corrected Directivity

≥ 42 dB, OSL calibration (OSLN50A-8, OSLNF50A-8, OSLN50-1, OSLNF50-1)

#### Return Loss Measurement Uncertainty (Standard OSL calibration. OSLN50-1 Precision Open/Short/Load calibration component.)







## **Internal Power Meter**

Frequency Measurement Frequency (for Cal Factor)

Amplitude Max Value, Min Value, Offset Value, Relative On/Off, Units dBm/Watts, Auto Scale, Fullscale

Calibration

Average Running Average, Max Hold (On/Off), Run/Hold, Average Mode (Continuous/Single)

Limit (On/Off), Upper Value, Lower Value Limits

50 MHz to 4 GHz Frequency Range Display Range -100 dBm to +100 dBm

Offset Range Max ± 100 dB, user settable value

Measurement Range -33 dBm to +20 dBm

> **VSWR** 1.5:1 typical

+27 dBm, ± 45 VDC (damage level) Maximum Power

Type N(m), 50  $\Omega$ Connector

± 0.7 dB (0 dBm, 1 GHz CW, @ 23 °C ± 3 °C) Accuracy

Frequency Response and Linearity Additional ± 0.8 dB (± 0.5 dB typical)

Temperature Effect Additional ± 0.02 dB per 1 °C change (typical)



## High Accuracy Power Meter (requires external USB Power Sensor)

Amplitude Maximum, Minimum, Offset, Relative On/Off, Units, Auto Scale

Average # of Running Averages, Max Hold

Zero/Cal Zero On/Off, Cal Factor (Center Frequency, Signal Standard)

Limite Limit On/Off Limit Unner/Lower

Limits	Limit On/Off, Limit U	pper/Lower			
Power Sensor Model	MA24105A	MA24106A	MA24108A/18A/26A	MA24208A/18A	MA24330A/40A/50A
Description	Inline High Power Sensor	High Accuracy RF Power Sensor	Microwave USB Power Sensor	Microwave Universal USB Power Sensor	Microwave CW USB Power Sensor
Frequency Range	350 MHz to 4 GHz	50 MHz to 6 GHz	10 MHz to 8/18/26 GHz	10 MHz to 8/18 GHz	10 MHz to 33/40/50 GHz
Connector	Type N(f), 50 Ω	Type N(m), 50 Ω	Type N(m), 50 Ω (8/18 GHz) Type K(m), 50 Ω (26 GHz)	Type N(m), 50 Ω	Type K(m), $50 \Omega$ (33/40 GHz) Type V(m), $50 \Omega$ (50 GHz)
Dynamic Range	+3 dBm to +51.76 dBm (2 mW to 150 W)	-40 dBm to +23 dBm (0.1 μW to 200 mW)	-40 dBm to +20 dBm (0.1 μW to 100 mW)	-60 dBm to +20 dBm (1 nW to 100 mW)	-70 dBm to +20 dBm (0.1 nW to 100 mW)
Measurand	True-RMS	True-RMS	True-RMS, Slot Power, Burst Average Power	True-RMS, Slot Power, Burst Average Power	Average Power
Measurement Uncertainty	± 0.17 dB <sup>a</sup>	± 0.16 dB <sup>b</sup>	± 0.18 dB <sup>c</sup>	± 0.17 dB <sup>d</sup>	± 0.17 dB <sup>e</sup>
Data sheet	11410-00621	11410-00424	11410-00504	11410-00841	11410-00906

Notes:

(for complete specifications)

- a. Expanded uncertainty with K=2 for power measurements of a CW signal greater than +20 dBm with a matched load.
- Measurement results referenced to the input side of the sensor.
  b. Total RSS measurement uncertainty (0 °C to 50 °C) for power measurements of a CW signal greater than –20 dBm with zero mismatch errors.
- c. Expanded uncertainty with K=2 for power measurements of a CW signal greater than -20 dBm with zero mismatch errors.
- d. Power uncertainty expressed with two sigma confidence level for CW measurement after zero operation. Includes
- calibration factor and linearity over temperature uncertainties, but not the effects of mismatch, zero set and drift, or noise. e. Includes linearity over temperature uncertainties, but not the effects of mismatch, zero set and drift, and



# Video Inspection Probe (Requires external USB Video Inspection Probe, sold separately)

## **Setup Parameters**

**Probe Models** G0306A or G0306B 400X USB Visual Inspection Probe

Tip Type (included with G0306A) SC\_APC\_F:, SC\_PC\_F:, LC\_PC\_F:, FC\_PC\_F:, 2.5APC\_M:, 2.5PC\_M:, 1.25PC\_M:

Test Profile (IEC 61300-3-35) SM PC >45:, SM APC:, SM PC >25:, MM PC 62.5:, MM PC 50.0:

> On/Off Auto Analyze On/Off Auto Filename

Auto Filename Settings Location, File Prefix, Start Number, Include Date

## **Measurement Parameters**

Live View Live Image

Capture Image for Analysis Captured

Analyze Analyze Image Results Table Auto/Off Overlay On/Off

Zoom Control Help Displays instruction for image Zoom feature

#### Save/Recall Parameters

Measurement (\*.vipi), VIP Image (\*.png), Screen Shot (.png) Save Recall Measurement (\*.vipi), VIP Image (\*.png), Screen Shot (.png)


Rename, Create Folder, Copy, Paste, Delete File Management

## **Report Parameters**


Customer, Project, Operator, Notes, Include Logo **Header Settings** 

Generate Report Generates pdf report with options to include multiple \*.vipi files

#### **Instrument Displays**



Dirty, oily fiber fails inspection



After proper cleaning, fiber passes 100%

# General Specifications

#### **Setup Parameters**

System Info Status, Battery

System Setups Date/Time, Language, Display/Audio Date/Time Time and Date Settings, Time Zone Settings

Language English, French, German, Italian, Spanish, Russian, Portuguese, Japanese, Korean, Chinese

Brightness, Color Schemes, Screen Shot Settings, Volume Display/Audio

GPS, Ethernet Configuration (DHCP/Static) Connectivity

Diagnostics Self Test

> Preset Preset, Reset, Update Firmware

Reset Factory Reset, Delete All User Files, Delete Custom Files, Master Reset

Save, Recall, File Management File

Measurement (\*.dat), Setup (\*.stp), Screen Shot (\*.png) Save

Recall Recall, Create Folder, Copy, Paste, Delete File Management Rename, Create Folder, Copy, Paste, Delete

Navigation Top, Bottom, Page Up, Page Down Help Menu System Info, FAQ, User Guide

Internal Trace/Setup Memory > 1000 files (files may be traces, setups, screen shots, or any combination)

External Trace/Setup Memory Limited only by size of USB Flash drive

#### Connectors

RF Out/Reflect In Type N, female, 50 Ω, Maximum Input +42 dBm, ± 50 VDC

InstaCal<sup>™</sup>/Power Meter Type N, male, 50 Ω, Maximum Input +27 dBm, ± 45 VDC (Damage Level)

External Power 5.5 mm barrel connector, 11 to 14 VDC, < 3.0 A

USB Ports USB 2.0 Type A (two ports)

USB Interface Type mini-B, Connect to PC for data transfer

#### Display

TFT Resistive Touch Screen Type Size

7.0 in daylight viewable color LCD

Resolution 800 x 480

Pixel Defects No more than five defective pixels (99.9986% good pixels)

## **GPS Connectivity** (external GPS USB module sold separately)

GPS Time/Location Indicator Time, Latitude, Longitude and Altitude in GPS dialog (current or last known location)

Time, Latitude, Longitude and Altitude with trace storage (current or last known location)

Clear Data, Synchronize system time to GPS Setup

#### **Battery**

Tvpe Li-Ion

**Battery Operation** > 8.0 Hours typical (70 % brightness setting, continuous usage)

> 7 days typical (With fully charged battery. Actual time will vary depending on battery charge level) Standby

#### **Regulatory Compliance**

EMC 2014/30/EU, EN 61326:2013, CISPR 11/EN 55011, IEC/EN 61000-4-2/3/4/5/6/8/11 European Union

Low Voltage Directive 2014/35/EU

Safety EN 61010-1:2010

RoHS Directive 2011/65/EU applies to instruments with CE marking placed on the market after July 22, 2017

Australia and New Zealand RCM AS/NZS 4417:2012

ICES-1(A)/NMB-1(A) Canada South Korea KCC-REM-A21-0004

#### **Environmental**

MIL-PRF-28800F Class 2 Operating Temperature Range -10 °C to 55 °C

Storage Temperature Range -51 °C to 71 °C Maximum Relative Humidity 95 % RH at 30 °C, non-condensing

> Vibration, Sinusoidal 5 Hz to 55 Hz Vibration, Random 10 Hz to 500 Hz

30 g<sub>n</sub> Half Sine Shock

Altitude 4600 meters, operating and non-operating

**Explosive Atmosphere** MIL-PRF-28800F Section 4.5.6.3

MIL-STD-810G, Method 511.5, Procedure 1

#### Size and Weight

250 mm x 177 mm x 61 mm (10.0 in x 7.1 in x 2.4 in) Size

< 2.0 kg (4.4 lb), including battery Weight

Warranty Duration Standard three-year warranty (battery one-year warranty)



# Anritsu Tool Box and Line Sweep Tools (for your PC)

Line Sweep Tools (LST) is a free PC based program that increases productivity for people who deal with numerous Cable and Antenna traces every day. LST is the next generation of Anritsu's familiar Handheld Software Tools (HHST) and shares its uncomplicated user interface, giving a new face to the term "ease of use."

Cable Editor <sup>1</sup>	Instrument Cable Lists may be retrieved from the instrument, modified as required, and uploaded back into instrument.
Distance to Fault <sup>2</sup> (DTF)	Easily convert Return Loss or VSWR traces to Distance to Fault traces with one button press.
Measurement Calculator	Provides quick conversion between commonly used measurement units such as VSWR, RL, and others.
Signal Standard Editor <sup>1</sup>	Signal Standard Lists may be retrieved from the instrument, modified as required, and uploaded back into instrument.
Naming Grid	A naming grid function makes changing file names, trace titles, and trace subtitles from field values to those required by contract simple and quick. Once the naming grid is populated with user defined file name segments, a few simple button presses will then fill out the file, title, and sub-title names. Quickly applied to multiple traces, the naming grid can save time, increase efficiency and accuracy.
Presets	Presets make applying markers and a limit line to similar traces quick and easy. They only need to be set once, and recorded. After this, applying them to a similar trace requires only one button push. This speeds up trace processing and makes providing consistent marker and limit line settings easy.
Report Generator	The report generator creates a professional PDF or HTML based report. Reports may include GPS <sup>3</sup> location, power level <sup>3</sup> , company logo <sup>4</sup> , instrument and calibration status along with a display of all open traces. It also may contain additional information such as addresses and phone numbers.
Cantura	Plots to Screen Database * dat * ing

Capture Plots to Screen, Database, \*.dat, \*.jpg Connect To PC using USB, Ethernet, Serial

Download/Upload<sup>1</sup> Lists/measurements and live traces to PC for storage and analysis. Supported File Types

Input: \*.dat, \*.vna, \*.mna, \*.pim, \*.tm

Output: \*.dat, \*.vna, \*.pim, \*.tm, \*.csv, \*.bmp, \*.jpg, \*.png



# easyTest Tools (for your PC)

Instrument Mode		
		Cable & Antenna Analyzer Mode
Commands		
	Display Image	Allows putting a custom image on the instrument screen
	Recall Setup	Places the instrument into a known state
	Prompt	Displays instructional messages on the instrument screen
	Save	Allows automatic or manual saving of traces

#### Connectivity

Connections USB cable or USB memory stick

Instrument type/model must match original
 Only \*.dat and \*.vna file types supported
 Model dependent
 Optionally set by user

# **Ordering Information**









#### **Model Number**

S331L (Includes all items listed in the description)

#### Description

Cable and Antenna Analyzer - 2 MHz to 4 GHz Internal InstaCal<sup>™</sup> - 2 MHz to 4 GHz Internal Power Meter - 50 MHz to 4 GHz

High Accuracy Power Meter

(requires External USB Power Sensor, sold separately)

GPS Location/System Time Sync

(requires External GPS Module 2000-1723-R, sold separately) Optical connector inspection with IEC 61300-3-35 based Pass/Fail standard

(requires USB Video Inspection Probe, sold separately)

# **Calibration and Extended Warranty Options**

. Warranty with Warranty **Z540 Calibration** S331L-ES510 S331L-ES513

#### Description

Warranty Extension to 5 Years, Return to Anritsu

# **Calibration Only Options**

Option S331L-0098

S331L-0099

Description

Standard Calibration to ISO17025 and ANSI/NCSL Z540-1.

Includes calibration certificate.

Premium Calibration to ISO17025 and ANSI/NCSL Z540-1. Includes calibration certificate, test report, and uncertainty

data.

# Standard Accessories (included with instrument)

Accessory

Description



2000-1676-R Soft Carrying Case



2000-1691-R Stylus with Coiled Tether

Certificate of Calibration and Conformance



Accessory

3-2000-1498 USB A/5-pin mini-B Cable, 10 ft

Description

2000-1687-R

Torque Multiplier N(m)



806-141-R Automotive Power Adapter, 12 VDC, 60 W



40-187-R AC-DC Adapter

ver Sensor, 20 dBm to -40 dBm	
20 dBm to -40 dBm ver Sensor,	
+20 dBm to -40 dBm	
ver Sensor, -20 dBm to -40 dBm	
MA24105A Inline Dual Directional High Power Sensor, 350 MHz to 4 GHz, +3 dBm to +51.76 dBm	
	, <del>†</del>



High Accuracy RF Power Sensor, 50 MHz to 6 GHz, +23 dBm to -40 dBm



MA25100A RF Power Indicator



SC8268

USB Transmission Sensor, K(m), 1 MHz to 40 GHz, +10 dBm to -50 dBm

# **Optional Accessories**

#### Backpack and Transit Case Accessory Description



67135 Anritsu Backpack (for Handheld Instrument and PC)

#### Accessory

#### Description



760-286-R Compact Transit Case with Wheels and Handle 55.6 cm x 35.5 cm x 22.9 cm (21.89" x 13.98" x 9.01")

USB Extender Kit (for use with external 2-port cable loss/transmission sensors; requires Cat 5e extension cable, sold separately)

#### Accessory Description

2000-1900-R

USB 2.0 Active 100 meter Extender (with Type A power cord for USA, Japan, North America, Central America and Caribbean)



Accessory

Description 2000-1717-R

USB 1.1 Passive 40 m Extender (Not compatible with sensors MA24208A, MA24218A, MA24330A, MA24340A, MA24350A; must use active extenders with these sensors.)



2000-1901-R

USB 2.0 Active 100 meter Extender (with Type C power cord for use in Europe, India, South Korea, and many countries in Middle East and Africa)



2100-28-R

Cat 5e extension cable for use with USB Extender (22.5 m)

2000-1902-R

USB 2.0 Active 100 meter Extender (with Type I power cord for use in Australia, New Zealand, Argentina, and the South Pacific)

2000-1903-R

USB 2.0 Active 100 meter Extender (with Type G power cord for use in the UK, and several other countries in Asia, the Middle East, and Africa)

#### **GPS Module**

#### Accessory

#### Description



2000-1723-R

High Performance USB Mag-Mount GPS Module

# Ethernet Adapter Accessory Description



2000-1810-R

Portable USB to Ethernet LAN Adapter

12 of 17 PN: 11410-00616 Rev. AA S331L TDS

#### **Video Inspection Probe** Accessory Description Accessory Description G0306B Video Inspection Probe (400x), including the following standard connector tips: Universal Tips: 971-14-R H0361A 1.25PC-M, H0360A 2.5PC-M, H0362A Ferrule Cleaner, 2.5 mm SC 2.5APC-M **Bulkhead Tips:** H0363A LC-PC-F, H0364A FC-PC-F, H0375A ST-PC-F, H0366A SC-APC-Additional Tips Available: 971-15-R H0372A E2000-PC-F, H0373A FC-APC-F, H0374A

MU-PC-F, H0365A SC-PC-F, H0376A 1.25APC-M




971-16-R Fiber Ferrule Cleaner

Ferrule Cleaner, 1.25 mm LC

Phase-Stab	le Test Port Cables, Armored w/Reinforced Grip	(recommended f	or cable & antenna line sweep applications)
Accessory	Description	Accessory	Description
	15RDN50-1.5-R		15RNFN50-1.5-R
	1.5 m, DC to 6 GHz, N(m) to 7/16 DIN(m), 50 $\Omega$	( 3	1.5 m, DC to 6 GHz, N(m) to N(f), 50 $\Omega$
	15RDFN50-1.5-R	~~	15RNFN50-3.0-R
C.7 6	1.5 m, DC to 6 GHz, N(m) to 7/16 DIN(f), 50 $\Omega$		3.0 m, DC to 6 GHz, N(m) to N(f), 50 $\Omega$
1	15RDN50-3.0-R		
	3.0 m, DC to 6 GHz, N(m) to 7/16 DIN(m), 50 $\Omega$		
	15RDFN50-3.0-R		

Interchangeable Adapter, Phase Stable Test Port Cables, Armored w/Reinforced Grip (recommended for cable and antenna line sweep applications. It uses the same ruggedized grip as the Reinforced grip series cables. Now you can also change the adapter interface on the grip

# to four different connector types.) Accessory Description 15RCN50-1.5-R



3.0 m, DC to 6 GHz, N(m) to 7/16 DIN(f), 50  $\Omega$ 

Accessory	<b>Die Test Port Cables, Armored</b> (recommended <b>Description</b>	d for use with tightly space <b>Accessory</b>	ed connectors and other general purpose applications  Description
Accessory	15NNF50-1.5C	Accessory	15NDF50-1.5C
	1.5 m, DC to 6 GHz, N(m) to N(f), 50 Ω		1.5 m, DC to 6 GHz GHz, N(m) to 7/16 DIN(f), 50 $\Omega$
	15NN50-1.5C		15ND50-1.5-R
	1.5 m, DC to 6 GHz, N(m) to N(m), 50 Ω	3	1.5 m, DC to 6 GHz, N(m) to 7/16 DIN(m), 50 $\Omega$
0	15NNF50-3.0C		15N43M50-1.5C
	3.0 m, DC to 6 GHz, N(m) to N(f), 50 Ω		Test Port Extension Cable, Armored, 1.5 m DC to 6 GHz, N(m) to 4.3-10(m)
	15NN50-3.0C		15N43F50-1.5C
	3.0 m, DC to 6 GHz, N(m) to N(m), 50 Ω		Test Port Extension Cable, Armored, 1.5 m, DC to 6 GHz, N(m) to 4.3-10(f)
	15NNF50-5.0C	_	15N43M50-3.0C
	5.0 m, DC to 6 GHz, N(m) to N(f), 50 Ω		Test Port Extension Cable, Armored, 3 m, DC to 6 GHz, N(m) to 4.3-10(m)
	15NN50-5.0C		15N43F50-3.0C
5.0 m, DC to 6 GHz, N(m) to N(m), 50 $\Omega$			Test Port Extension Cable, Armored, 3 m, DC to 6 GHz, N(m) to 4.3-10(f)

#### Coaxial Calibration Components, 50 $\Omega$ Accessory Description



22NF50 Open/Short, N(f), DC to 18 GHz, 50  $\Omega$ 



Description



OSLN50A-8 High Performance Type N(m), DC to 8 GHz, 50  $\Omega$ 



OSLNF50A-8 High Performance Type N(f), DC to 8 GHz, 50  $\Omega$ 



2000-1914-R Precision Open/Short/Load, 4.3-10(f), DC to 6 GHz, 50  $\Omega$ 



2000-1915-R Precision Open/Short/Load, 4.3-10(m), DC to 6 GHz, 50  $\Omega$ 



2000-1618-R Precision Open/Short/Load, 7/16 DIN(m), DC to 6.0 GHz, 50  $\Omega$ 



2000-1619-R Precision Open/Short/Load, 7/16 DIN(f), DC to 6.0 GHz 50  $\Omega$ 



22N50 Open/Short, N(m), DC to 18 GHz, 50  $\Omega$ 



SM/PLNF-1 Precision Load, N(f), 4 dB, 6.0 GHz, 50  $\Omega$ 



SM/PL-1 Precision Load, N(m), 4 dB, 6.0 GHz, 50  $\Omega$ 

#### Coaxial Calibration Components, 75 Ω Accessory Description



22N75 Open/Short, N(m), DC to 3 GHz, 75  $\Omega$ 



Description



22NF75 Open/Short, N(f), DC to 3 GHz, 75  $\Omega$ 



26N75A Precision Termination, N(m), DC to 3 GHz, 75  $\Omega$ 



26NF75A Precision Termination, N(f), DC to 3 GHz, 75  $\Omega$ 



12N50-75B Matching Pad, DC to 3 GHz, 50  $\Omega$  to 75  $\Omega$ 

#### Adapters Accessory

#### Description



1091-26-R SMA(m) to N(m), DC to 18 GHz, 50  $\Omega$ 



1091-27-R SMA(f) to N(m), DC to 18 GHz, 50  $\Omega$ 



1091-80-R SMA(m) to N(f), DC to 18 GHz, 50  $\Omega$ 



1091-81-R SMA(f) to N(f), DC to 18 GHz, 50  $\Omega$ 



1091-172-R BNC(f) to N(m), DC to 1.3 GHz, 50  $\Omega$ 



1091-435-R Low PIM Adapter, 4.1-9.5(f) to N(m), DC to 3.0 GHz, 50  $\Omega$ 



1091-436-R Low PIM Adapter, 4.1-9.5(m) to N(m), DC to 3.0 GHz, 50  $\Omega$ 



1091-434-R Low PIM Adapter, 4.1-9.5(m) to 7/16 DIN(f), DC to 3.0 GHz, 50  $\Omega$ 



1091-465-R Adapter, DC to 6 GHz, 4.3-10(f) to N(f), 50  $\Omega$ 



1091-440-R Low PIM Adapter, 4.3-10(f) to 7/16 DIN(f), DC to 6.0 GHz, 50  $\,\Omega$ 



#### Accessory

#### Description



510-102-R N(m) to N(m), DC to 11 GHz, 50  $\Omega,$  90 degrees right angle



510-90-R 7/16 DIN(f) to N(m), DC to 7.5 GHz, 50  $\Omega$ 



510-91-R 7/16 DIN(f) to N(f), DC to 7.5 GHz, 50  $\Omega$ 



510-92-R 7/16 DIN(m) to N(m), DC to 7.5 GHz, 50  $\Omega$ 



510-93-R 7/16 DIN(m) to N(f), DC to 7.5 GHz, 50  $\Omega$ 



510-96-R 7/16 DIN(m) to 7/16 DIN (m), DC to 7.5 GHz, 50  $\Omega$ 



510-97-R 7/16 DIN(f) to 7/16 DIN (f), DC to 7.5 GHz, 50  $\Omega$ 



1091-433-R Low PIM Adapter, 4.1/9.5(f) to 7/16 DIN(f), DC to 3.0 GHz, 50  $\Omega$ 



1091-467-R Adapter, DC to 6 GHz, 4.3-10(m) to N(f), 50  $\Omega$ 



1091-441-R Low PIM Adapter, 4.3-10(m) to 7/16 DIN(f), DC to 6.0 GHz, 50  $\Omega$ 



1091-443-R Low PIM Adapter, 4.3-10(m) to N(m), DC to 6.0 GHz, 50  $\Omega$ 

#### **Precision Adapters** Description Accessory



34NN50A N(m) to N(m), DC to 18 GHz, 50  $\Omega$ 

#### Accessory

#### Description

Description



34NFNF50 N(f) to N(f), DC to 18 GHz, 50  $\Omega$ 

# **Attenuators**

#### Accessory

#### Description



1010-121-R 40 dB, 100 W, DC to 18 GHz, N(f) to N(m), Un-idirectional



Accessory

42N50-20 20 dB, 5 W, DC to 18 GHz, N(m) to N(f)



3-1010-122 20 dB, 5 W, DC to 12.4 GHz, N(m) to N(f)



42N50A-30 30 dB, 50 W, DC to 18 GHz, N(m) to N(f)



3-1010-123 30 dB, 50 W, DC to 8.5 GHz, N(m) to N(f)



1010-127-R 30 dB, 150 W, DC to 3 GHz, N(m) to N(f)



3-1010-124 40 dB, 100 W, DC to 8.5 GHz, N(f) to N(m), Uni-directional



1010-128-R 40 dB, 150 W, DC to 3 GHz, N(m) to N(f)

#### **Documentation** (available at www.anritsu.com)

# Part Number Description

10100-00065 Product Information, Compliance, and Safety 11410-00616 Site Master<sup>™</sup> S331L Technical Data Sheet 10580-00321 Site Master<sup>™</sup> S331L User Guide

11410-00640

Site Master S331L Product Brochure

(Includes information about additional Site Master models)

11410-00662 Site Master S331L Quick Fact Sheet 11410-00674 Cable and Antenna Analysis Troubleshooting Guide

10580-00253 Site Master<sup>™</sup> S331L Maintenance Manual

# Training at Anritsu

Anritsu has designed courses to help you stay up to date with technologies important to your job. For available training courses, visit: www.anritsu.com/training



# Jälleenmyyjä:

# Orbis Oy

Vanha Kaarelantie 9, 01700 Vantaa 020 478 8600

www.orbis.fi - www.worbis.fi

# **INCITSU** Advancing beyond

#### United States

#### **Anritsu Americas Sales Company**

450 Century Parkway, Suite 190, Allen, TX 75013, U.S.A. Phone: +1-800-Anritsu (1-800-267-4878)

#### Canada

#### Anritsu Electronics Ltd.

700 Silver Seven Road, Suite 120, Kanata, Ontario K2V 1C3, Canada Phone: +1-613-591-2003 Fax: +1-613-591-1006

#### Brazil

#### Anritsu Eletronica Ltda.

Praça Amadeu Amaral, 27 - 1 Andar 01327-010 - Bela Vista - Sao Paulo - SP, Brazil Phone: +55-11-3283-2511 Fax: +55-11-3288-6940

Anritsu Company, S.A. de C.V. Blvd Miguel de Cervantes Saavedra #169 Piso 1, Col. Granada, Mexico, Ciudad de Mexico, 11520. MEXICO Phone: +52-55-4169-7104

#### United Kingdom

#### Anritsu EMEA Ltd.

200 Capability Green, Luton, Bedfordshire, LU1 3LU, U.K. Phone: +44-1582-433200 Fax: +44-1582-731303

#### France

#### Anritsu S.A.

12 avenue du Québec, Immeuble Goyave, 91140 VILLEBON SUR YVETTE, France Phone: +33-1-60-92-15-50

#### Germany

#### Anritsu GmbH

Nemetschek Haus, Konrad-Zuse-Platz 1, 81829 München, Germany Phone: +49-89-442308-0 Fax: +49-89-442308-55

#### Italy

#### Anritsu S.r.l.

Spaces Eur Arte, Viale dell'Arte 25, 00144 Roma, Italy Phone: +39-6-509-9711

#### • Sweden

#### Anritsu AB

Kistagången 20 B, 2 tr, 164 40 Kista, Sweden Phone: +46-8-534-707-00

#### Anritsu AB

Technopolis Aviapolis, Teknobulevardi 3-5 (D208.5.). FI-01530 Vantaa, Finland Phone: +358-20-741-8100

#### Anritsu A/S

c/o Regus Winghouse, Ørestads Boulevard 73, 4th

2300 Copenhagen S, Denmark Phone: +45-7211-2200

#### Russia

# Anritsu EMEA Ltd.

Representation Office in Russia Tverskaya str. 16/2, bld. 1, 7th floor,

Moscow 125009, Russia Phone: +7-495-363-1694 Fax: +7-495-935-8962

#### Spain

#### Anritsu EMEA Ltd.

#### Representation Office in Spain

Paseo de la Castellana, 141 Planta 5, Edificio Cuzco IV 28046, Madrid, Spain Phone: +34-91-572-6761

#### Anritsu FMFA GmbH

Am Belvedere 10, A-1100 Vienna, Austria Phone: +43-(0)1-717-28-710

#### United Arab Emirates

# Anritsu EMEA Ltd.

#### Anritsu A/S

Office No. 164, Building 17, Dubai Internet City P. O. Box - 501901, Dubai, United Arab Emirates Phone: +971-4-3758479

#### Anritsu India Private Limited

6th Floor, Indiqube ETA, No.38/4, Adjacent to EMC2, Doddanekundi, Outer Ring Road, Bengaluru – 560048, India Phone: +91-80-6728-1300 Fax: +91-80-6728-1301

#### Singapore

#### Anritsu Pte. Ltd.

11 Chang Charn Road, #04-01, Shriro House Singapore 159640 Phone: +65-6282-2400 Fax: +65-6282-2533

#### Vietnam

#### **Anritsu Company Limited**

16th Floor, Peakview Tower, 36 Hoang Cau Street, O Cho Dua Ward, Dong Da District, Hanoi, Vietnam Phone: +84-24-3201-2730

#### P.R. China (Shanghai)

#### Anritsu (China) Co., Ltd.

Room 2701-2705, Tower A, New Caohejing International Business Center No. 391 Gui Ping Road Shanghai, 200233, P.R. China Phone: +86-21-6237-0898 Fax: +86-21-6237-0899

#### P.R. China (Hong Kong)

#### Anritsu Company Ltd.

Unit 1006-7, 10/F., Greenfield Tower, Concordia Plaza, No. 1 Science Museum Road, Tsim Sha Tsui East, Kowloon, Hong Kong, P.R. China Phone: +852-2301-4980 Fax: +852-2301-3545

#### Japan

#### **Anritsu Corporation**

8-5, Tamura-cho, Atsugi-shi, Kanagawa, 243-0016 Japan Phone: +81-46-296-6509

# Fax: +81-46-225-8352

South Korea

# Anritsu Corporation, Ltd.

5FL, 235 Pangyoyeok-ro, Bundang-gu, Seongnam-si, Gyeonggi-do 13494, South Korea +82-31-696-7750 Fax: +82-31-696-7751

#### Australia

#### Anritsu Ptv. Ltd.

Unit 20, 21-35 Ricketts Road, Mount Waverley, Victoria 3149, Australia Phone: +61-3-9558-8177 Fax: +61-3-9558-8255

#### Taiwan

#### Anritsu Company Inc.

7F, No. 316, Sec. 1, NeiHu Rd., Taipei 114, Taiwan Phone: +886-2-8751-1816 Fax: +886-2-8751-1817

List Revision Date: 20210610